## WOODEN DOOR HANGING SLIDING ROLLER

Wooden Door Incongruous Two Linkage Hanging Sliding Roller System Instruction(2+2)

Accessory List:

Accessories			Quai (PC	ntity CS)	А	Accessories		Quantity (PCS)
Outside rollers				1	Inside rollers with damper			1
Inside rollers				1	Outside rollers with damper			1
Belt fixing p		1	Damper stopper			2		
Linkage rur	2	2	M4*6 screw			2		
Transmissio		1	Wooden door down guiding roller			2		
ST3.5*12 cross countersunk head tapping screws			2	Wooden door hanging plate			4	
2mm allen key			1		M4*12 inner hexagon screw		8	
2.5mm alle	1		3mm extended allen key		1			
4mm allen key			,	ST4*30 c tapping s		cross countersunk head screws		20
Function	Door width	Single door capac			thickness	Installation	Ins	stallation
Double soft close	530mm -1200mm	60-100Kg		35-60mm		Top install with side hanging plate	Fixed door d	tovable Movable Fixed door oor 1 door 2



Fixed door accessories are optional

## 2.Rail accessory assembling

1. Insert the incongruous synchronous rollers, damper stoppers and rollers into the rail in sequence, as shown in the picture.Door stoppers put in each end of track while rollers in the middle. Make sure that there are no impurity or aluminum scraps in the rail before installation.

- 2. Pull the rollers manually. If there's no abnormal noise, fix the rail to the ceiling with self-tapping screws.



## 3.Linkage belt assembling

Pass the synchronous belt through the incongruous gearing wheel at both ends of the upper rail and plastic part on the hanging box, and connect the two ends of belt through the belt fixing part. The belt fixing part must be locked with 2 mm inner hexagon screw through M4\*4 screws, the belt fixing part is fixed to the hanging box through M4\*6 screw without any looseness.



## 4.Door accessory assembling

Install the hanging box above the door, and the convex part of the hanging box facing inward, fix down rail under door with self-tapping screws. screw head must not be higher than the bottom of down rail.

Note: Head of the screws must not be higher than the surface of the down rail. 5.Door assembling Fix top installed hanging plate from the side of the mounting plate through M4\*12 inner hexagon screw by 2.0 inner hexagonal wrench, fixed the screw without any looseness. 6.Down guider assemble instuction After the door is installed, close the doors and move the door to the middle, install the down guider wheel as shown in the picture. Movab door 2 Movable door 1

